


ZDUP

109..

110..

111..

112..



1

Montaggio Assembly



$65 \pm 5^\circ\text{C}$




$15 \pm 5^\circ\text{C}$



MIN - MAX





OK





3
a

110
112





112


b







110





c



FFunzionamento
Working109
111110
112

M

Manutenzione Service





Sostituzione Cartuccia
How to replace Cartridge

110

112

